
NEXOGE®

USER'S MANUAL

AIR MASK IONIC AIR PURIFIER AM01



- 1 I ANYARD
- 2. IONS RELEASE BRUSH
- 3. LED
- 4. ON/OFF KEY
- 5. USB CHARGE SOCKET

PACKAGE CONTAIN

- AM01 X 1
- LANYARD X 1
- · USB CHARGE CABLE X 1
- USER'S MANUAL X 1

MAIN FEATURES

- Produce 20 million Air IONs per second per cm³
- · Subside Airborne Pollutants include:
- ▶ Particulate Matter PM2.5
- ▶ Pollen
- ▶ Smoke
- ► Other Allergens
- The tailor-made Lanyard will enhance the ionizing performance



- One Key Startup
- · LED shows the unit in work
- · Long Operation Time up to 18 hours
- Eco-Friendly Battery (Non-Lithium Battery)
- Overheat Protection (Working / Charging)

IMPORTANT NOTES

- · Read this manual before use the product.
- The lanyard provided is tailor-made to enhance the ionizing performance. Replace with other lanyard may degrade the performance.

SAFETY NOTES

- Avoid using this product on baby or person in need of care.
- Person with Heart Disease or using Artificial Pacemaker <u>MUST NOT</u> use this product
- MUST NOT use the product in the environment with flammable gas, combustible gas & volatile liquid, e.g. petrol station & LPG filling station.
- · Do not use the unit on bed, cover by quilt or blanket.
- If you are allergy with the lanyard, please stop using this product.
- Do not expose or store the unit in front of / close to heat source, high temperature environment and fire.
- Do not put the unit into water or liquid. Avoid getting wet inside the unit
- · Place the unit well to avoid drop down.
- Clean the unit by using a dry cloth during OFF mode. Do not use alcohol, solvents or abrasives etc.
- Do not attempt to open the unit, or otherwise, the unit will be damaged.

- Do not use or charge the unit if you find the plastic case opened or broken.
- During operation, avoid touching the IONs Release Brush with skin, or otherwise, it may affect the function or you may feel slight sting.

CAUTION: THIS DEVICE CONTAINS BATTERIES, KEEP IT AWAY FROM FIRE OR HEAT.

LANYARD

· Please tie up the lanyard with the unit.

POWER ON/OFF

- To power ON the unit, press the ON/OFF Key once and Blue LED turn on. The unit will start to produce IONs.
- To power OFF the unit, press & hold the ON/OFF key and the Blue LED turn off.

BATTERY LOW

 When the battery power too low, the unit will be auto off, please re-charge the unit asap.

CHARGING

- Plug the Micro USB cable into the unit charge socket at the bottom
- Plug the USB cable into a USB 5V1A adaptor (Not Included).
- During charging, the **RED LED** will turn on.
- Charge the unit for 6~8 hours and unplug the cable before use
- As the Lanyard is conductive, please put it away from the adaptor during charging.
- · You can keep the unit in use during charging.

SAFETY NOTES ON BATTERY

- The unit is using Non-Lithium battery that is safe from burn out.
- The unit is well designed for continuous charging from 8-10 hours and protected from overheat during operation or charging. As such, there is no indication on battery fully charged.
- Please charge the unit for at least 6 hours and unplug the charge cable after 8-10 hours charging.
- To extend the battery life, please charge the unit once a week for 6 hours or above.

SPECIFICATIONS		
Voltage	:	DC 3.6V
IONs produced	:	> 20 million /sec/cm3
Operating Temperature	:	0°C to +45°C
Size W.H.D.	:	23 x 65 x 19mm
Product Weight	:	27.5 g

REMARKS

The IONs count and battery life figures mentioned are based on in-house measurement. The product performance may be varied